
Honeywell Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode



999999

2. Load RS232 Defaults



999980

3. Exit Program Mode



999999

Copyright 2017, Honeywell International, Inc.