




web'n'walk Stick


Quick start guide




..... T-Mobile

Getting Started...

1. Pull the cap off the web'n'walk Stick.
2. Pull out the SIM card holder, and insert your SIM card, as shown below. Check that the SIM card is correctly positioned.
3. Slide the SIM card holder back into the web'n'walk Stick, as shown below.



4. Turn your computer on before inserting the web'n'walk Stick.
5. Insert the web'n'walk Stick into an available USB port on your computer (the location of USB ports varies depending on the computer model).



If preferred, you can connect the web'n'walk Stick to your computer using the USB cable provided.

Next steps for Windows

6. Your computer automatically detects the web'n'walk Stick as new hardware and automatically starts the web'n'walk Stick Manager Setup Wizard.

If running Windows Vista you may need to click 'Run AutoRun.exe'.

Note: If the Setup Wizard does not start automatically, go to 'My Computer' (if running Windows 2000/XP) or 'Computer' (if running Windows Vista). Double-click web'n'walk . Then double-click the AutoRun.exe file to launch the Setup Wizard.

7. Select the installer language you want and click **OK**.

8. Click **Next** to start installation.

Note: Do not disconnect the web'n'walk Stick during the installation process.

9. Select 'T-Mobile UK' and click **Next**.

10. If you agree to the licence agreement terms, click **I Agree**.

11. Choose to accept the default folder by clicking **Next** or change the location by clicking **Browse**.

12. Click **Install**.

13. When installation is completed, click **Finish**.

14. After successful installation the web'n'walk Stick Manager short-cut icon  will appear on your desktop.

15. Please wait a few moments for web'n'walk Stick Manager to start automatically. If it does not start in 3 minutes double-click the web'n'walk Stick Manager icon  on your desktop.

Enter your SIM card PIN if prompted. This will have been provided with your SIM card.

16. Click  Connect (this will become a  Disconnect button once you are connected).

17. Click  Internet to open the web browser and start using the Internet!

Next steps for Apple Mac

6. Your computer will automatically detect the web'n'walk Stick, double-click the web'n'walk Stick Manager icon.
7. Click **Continue** to start installation.
8. If you agree to the licence agreement terms, click **Continue** then **Agree**.
9. Choose to accept the standard installation folder by clicking **Install** or change the location by clicking **Change Install Location**.
10. Enter your password, if prompted.
11. When installation is completed, click **Close**.
12. After successful installation web'n'walk Stick Manager will start automatically.

Enter your SIM card PIN if prompted. This will have been provided with your SIM card.

13. Click the Connect button. The Connect button will become a Disconnect button once you are connected.

You will be prompted to enter your password (you will only need to do this once).

14. Open the web browser and start using the Internet!

System requirements

Windows

- Microsoft Windows Vista 32-bit and 64-bit (Business Edition, Enterprise Edition, Ultimate Edition, Home Premium Edition, Home Basic Edition), Microsoft Windows XP Professional (SP1, SP2), Microsoft Windows XP Home Edition (SP1, SP2), Microsoft Windows XP Tablet PC Edition (SP1, SP2), Microsoft Windows XP Media Center Edition (SP1, SP2), Microsoft Windows 2000 (SP4)
- 256 MB RAM or more
- 25 MB hard-disk drive space or more
- Internet Explorer Version 5.5 or higher
- USB 2.0 Port

Mac OS

- Mac PowerBook
- Mac OS X 10.3.7 or higher
- 5 MB hard-disk drive space or more
- USB 2.0 Port

Contact us

For technical help including FAQ's, troubleshooting and downloads go to **www.t-mobile.co.uk/datacardhelp**. If you can't find what you're looking for on the website, then call us on **0845 412 2993** (charged at local rate).

If you have a more general enquiry then please call **150** free from your mobile or **0845 412 5000** (charged at local rate).

T-Mobile Customer Services is open from 7am to 10pm everyday.



T-Mobile